



Season of Navigation.
 The Ordinary Open Season of Navigation is from April 25th to November 25th - seven months - and frequently lasts from April 20th to November 30th.

Depth of Water.
 There are no Tides. The Harbour and River Level during the season of Navigation, is highest in May, giving an average depth of 50 feet in the 50 foot Ship Channel, and lowest in October and November, when the average depth is 30 to 40 feet.

Boundaries of The Harbour of Montreal.
 8-9 Edward VII, Chap. 24, May 1909.

The Eastern and Western Boundaries are defined by the natural banks of The River St. Lawrence, at High Water Mark. The Northern Boundary extends from High Water Mark, at the extreme Northern end of The Island of Montreal, at Bois de l'Isle, 9 1/2 Miles below Longue Pointe Church, across The River St. Lawrence, bearing due East astronomically, to the High Water Mark on the opposite shore. The Southern Boundary extends across The River St. Lawrence, from High Water Mark, to High Water Mark, 3760 feet above, and parallel to, the Victoria Bridge.

PLAN OF THE SOUTHERN PORTION OF THE HARBOUR OF MONTREAL
 PREPARED IN 1924 BY
 The Harbour Commissioners of Montreal
 DR. W. L. M. DOUGALD, President.
 EMILIE DAoust, DR. MILTON L. HERSEY.

T. W. HARVIE, General Manager.
 J. P. LECLAIRE, Chief Engineer.
 T. E. TRIHEY, Secretary.

SCALE 1:25,000
 FT. 100 0 1000 2000 3000 4000 5000 6000 FT.
 0 1/4 1/2 3/4 1 MILE